


How to connect for Read and Write the ENGINE



Connect as below:


Serial Suite:

Red
Black
Green


to
to
to

ECU Plug:

2 Pins Red (Power Supply +12 Volt)
2 Pins Black (Ground)
1 Pins Green (K Line)




How to connect the ecu



Connect the 4 wire (Bridge) like in the picture, now you can read and write the ECU.

How to connect for READ and WRITE the GEARBOX



Connect as below:


Serial Suite:

Red
Black
Green


to
to
to

ECU Plug:

2 Pins Red (Power Supply +12 Volt)
2 Pins Black (Ground)
1 Pins Green (K Line)



How to connect the ecu.



Connect the 4 wire (Bridge) like in the picture, now you can read and write the ECU.