


# PIASINI

engineering



Connect as below:


Serial Suite:

Red  
Black


to  
to

ECU Plug:

2 Pins Red (Power Supply +12 Volt)  
1 Pins Black (Ground)





Where to connect the flat cable:





## READ the ECU

10			
5	15	14	
12	13	11	3



Connect the flat cable following the number in the picture.

