

Connect as below:

Serial Suite:

ECU Plug:

Red


to

1 Pins Red (Power Supply +12 Volt)



Black

to

1 Pins Black (Ground)



Where to connect the flat cable:






This is where you have to connect the flat cable.

Piasiniengineering info@piasiniengineering.it – <http://www.piasiniengineering.it>



Tel: +39 0342 489060 - Fax: +39 0342 488298

READ the ECU:


Ecu front:



Ecu back:



WRITE the ECU:



For write the ECU put 2 wire(Bridge) like in the picture.