

Connect as below:

Serial Suite:

ECU Plug:

Red


to

1 Pins Red (Power Supply +12 Volt)


Black

to

1 Pins Black (Ground)






Where to connect the flat cable:



This is where you have to connect the flat cable.

READ the ECU:


Step 1:



You have to remove the 3 resistor, and put 4 wire (bridge), like in the picture.

READ the ECU:

Step 2:



20

3 15 14 13 12 10 5

11

1


2

19

Connect the flat cable pin following the number like in picture.



WRITE the ECU:



For write the ECU put 2 wire(Bridge) like in the picture.